

PTS190 Release – Requirements for DESK1500 & IPP315 PINPads

1. The DESK1500 PINPad will only work on PCI V4 terminals that are running PTS190 Software. **V4 Terminals with PTS2018.1 are not compatible with the DESK1500.**

| DESK 1500 Compatibility | | | |
|-------------------------|--------|----------|--|
| | PCI V4 | PCI V5 | |
| PTS2018.1 | × | ✓ | |
| PTS190 | ✓ | ✓ | |

The IPP315 PINPad is only certified for PCI-PTS v4.x terminals.
We advise you that the IPP315 Pinpad IS NOT to be connected to the PCI-PTS v5.x terminals as this will introduce unexpected issues.

| IPP315 Compatibility | | | |
|----------------------|----------|--------|--|
| | PCI V4 | PCI V5 | |
| PTS2018.1 | ✓ | × | |
| PTS190 | ✓ | × | |

3. Once an IPP315 PINPad upgrades to PTS190, it will no longer be compatible with PTS2018.1. **Do not try and attach an IPP315 PINPad running PTS190 to a terminal running PTS2018.1**

| IPP315 Upgrade | | | | |
|----------------|---------------|-----------|---|--|
| PTS2018.1 | \rightarrow | PTS190 | ✓ | |
| PTS190 | \rightarrow | PTS2018.1 | × | |